K 2 Full Control

The K 2 Full Control is a powerful and lightweight power cleaner, which gives you targeted pressure regulation for light dirt, found on bicycles, garden tools and garden furniture.

MISSING PIC-TURE: D:\ IM0027641

1 Full Control Click Vario Power spray lance and Dirt Blaster

- Gives you direct feedback as to the pressure setting you are on, ensuring you get the right pressure setting for the surface you are trying to clean.
- Settings are chosen by turning the Full Control Click Vario Power spray lance

2 Supports for accessories, high-pressure gun and cable

- Spray lances are always within easy reach and everything can be compactly stored on the device once cleaning is complete.
- Not all living spaces come with generous storage space. The Kärcher K2 home pressure washer's upright design saves you space, while the on-board storage solutions keep your Kärcher accessories, cables plus hose and trigger gun stored neatly on the machine.

3 Detergent use

- Suction hose for use of detergents.
- Kärcher detergents increase efficiency while cleaning, help prevent dirt from returning and help to protect and care for your surface.

4 Telescopic handle

- For a convenient pulling height.
- Completely retractable for a compact storage solution.

K 2 Full Control, 1.673-402.0, 2019-04-05

TECHNICAL DATA AND EQUIPMENT.

KÄRCHER

K 2 Full Control

- Full Control Click Vario Power spray lance with pressure setting display
- Extendable telescopic handle
- Spray lance storage

Technical data

Order Number		1.673-402.0
EAN code		4054278158181
Pressure	**bar / MPa**	20-110 / 2-11
Flow rate	**l/h**	360
Max. water feed temperature	**°C**	max. 40
Power rating	**kW**	1,4
Weight without accessories	**kg**	4,3
Dimensions (L x W x H)	**mm**	246 × 280 × 586
Current type	**V**	230-240
Area performance	**m²/h**	20

Equipment

High-pressure gun		G 120 Q
Vario Power spray lance		-
Dirt Blaster spray lance		■
High-pressure hose	**m**	4
Quick Connect on machine		■
Detergent application via		Suction
Integrated water filter		■
Adapter garden hose A3/4"		■
Click VPS		■

■ **Included in delivery.**

K 2 Full Control, 1.673-402.0, 2019-04-05

K 2 FULL CONTROL
1.673-402.0

KÄRCHER

1

2

3

4

5

6

7

8

9

10

11

12

13

15

		Order Number					Price	Description	
Spray lances									
Full Control Vario Power Jet for K2 - K3, VP120	1	2.642-724.0						Vario Power spray lance for pressure washers in the K2–K3 range. With continuously adjustable pressure by simply by turning the spray lance, you will have a setting for every task.	■
Full Control Dirt Blaster for K2 - K3, DB120	2	2.642-727.0						Dirt Blaster spray lance for K2 and K3 Kärcher pressure washers. This lance is perfect for tackling tough, stuck-on dirt like that on mossy or weathered surfaces.	■
Telescopic jet pipe	3	2.642-347.0						The Kärcher Telescopic jet pipe allows for easy cleaning of difficult to reach areas. With a shoulder strap and an ergonomically adjustable trigger gun, allwoing you to reach up to 4m.	□
Splash guard	4	2.642-706.0						The transparent splash guard for K2 to K7 Kärcher pressure washers protects you and the surrounding area from spray water. Ideal for cleaning corners and edges.	□
Angled spray lance	5	2.638-817.0						Extra-long angled spray lance (about 1 m) for easy cleaning of difficult to reach areas, e.g. roof gutters or vehicle underbodies.	□
Single Lance Extension	6	2.643-240.0						Extends spray lance by 0.5 m. For effective cleaning of difficult to reach areas. Suitable for all Kärcher accessories.	□
Mini VP160 Vario Power Jet	7	2.643-254.0						The Kärcher Mini Vario Power Jet comes with infinite pressure regulation and an adjustable 360° joint, ideal for cleaning difficult to reach areas. For use with K2 - K7 pressure washers.	□
Hard surface cleaners									
PS 40 Power Scrubber	8	2.643-245.0						The Kärcher PS40 power scrubber comes with three integrated high-pressure nozzles giving you a powerful, reliable and time-saving solution for removing stubborn dirt on a variety of surfaces.	□
T350 Patio Cleaner	9	2.643-252.0						The Kärcher T350 patio cleaner allows you to clean large areas quickly and efficiently, as well as being splash-free. This model includes adjustable cleaning pressure for different surfaces.	□
Spare nozzles accesories	10	2.643-338.0						High-quality replacement nozzles for all T-Racer surface cleaners (except T 350) for unit classes K 2 to K 7, gutter cleaner PC 20 for K 3 to K 7, as well as chassis cleaner for K 2 to K 5.	□
Spare nozzles accesories T 300 / T 350	11	2.643-335.0							□
Special applications									
FJ 6 foam nozzle	12	2.643-147.0						The Kärcher FJ6 foam nozzle is the perfect addition to your Kärcher pressure washer, allowing you to add a layer of foamy detergent with the minimum of effort and fuss.	□
Foam nozzle Connect 'n' Clean FJ10 C Ultra Foam Cleaner 1L	13	2.643-143.0						The Kärcher Ultra Foam Detergent & FJ10 C Connect ‚n' Clean foam nozzle is the most effective way to apply deteregent. Allowing you to switch between detergents for different tasks.	□
FJ 10 C Connect 'n' Clean Foam and Care nozzle with Car Shampoo	14	2.643-144.0						Car Shampoo & FJ 10 C Connect ‚n' Clean foam nozzle - The most effective way to apply deteregent. Also allows a simple switch between different detergents for different tasks.	□
Roof gutter and pipe cleaning set	15	2.642-240.0						The Kärcher roof gutter and pipe cleaning kit is an effective way to clean and remove blockages in pipes, drains, downpipes and toilets. Compatible with all Kärcher pressure washers.	□

■ Included in delivery. □ Available accessories.

K 2 FULL CONTROL
1.673-402.0

KÄRCHER

16

17

18

19

21

22

23

24

25

26

27

28

29

30

		Order Number					Price	Description	
Pipe cleaning set, 15 m	16	2.637-767.0						Pipe cleaning set with 15 m hose for clearing blockages in pipes, drains, downpipes and toilets.	□
Pipe cleaning set, 7.5 m	17	2.637-729.0						Pipe cleaning set with 7.5 m hose for clearing blockages in pipes, drains, downpipes and toilets.	□
Vario joint	18	2.640-733.0						Vario joint, rotates 180° for cleaning difficult to reach areas. Connection: For connection between gun and accessory or extension lance and accessory.	□
Kärcher organiser	19	2.641-630.0						Kärcher organiser, the practical wall-mounted storage system for Kärcher accessories. With two modules for flexible mounting. Ideal for protecting wash brushes and bristles from bending.	□
FJ 10 C Connect 'n' Clean Foam and Care nozzle with Stone Cleaner	20	2.643-145.0						3in1 Stone cleaner & FJ 10 C Connect ‚n' Clean foam nozzle - The most effective way to apply deteregent. Also allows a simple switch between different detergents for different tasks.	□
Sand/wet blasting set	21	2.638-792.0						Sand and wet blasting set for removing rust, paint and stubborn dirt using Kärcher abrasive.	□
Brushes									
WB 150 power brush	22	2.643-237.0						The Kärcher WB150 pressure washer brush is the perfect attachment for cleaning delicate surfaces such as car exteriors, motorbikes, glass, garage doors and conservatories.	□
WB60 Soft Surface Wash Brush	23	2.643-233.0						The Kärcher WB60 soft wash brush is a great addition to your Kärcher pressure washer to help you clean larger surfaces like cars, caravans, boats and conservatories.	□
Wheel Washing Brush	24	2.643-234.0						The Kärcher wheel washing brush is perfect for removing dirt and grime that accumulates on your wheel rims. With 360° degree cleaning enabiling you to reach every angle of your wheels.	□
Adapter for garden hose connection	25	2.640-732.0							□
WB100 Rotating Wash Brush	26	2.643-236.0						The Kärcher WB100 rotating wash brush is ideal for cleaning all smooth surfaces like paint, glass or plastic. It comes with a 180° joint making it infinitely adjustable.	□
WB 120	27	2.644-060.0							□
WB 120 Car & Bike	28	2.644-129.0							□
Washing brush rigid	29	6.903-276.0						Standard Kärcher brush for pressure washers. Perfect for removing stubborn dirt and cleaning a wide variety of firm surfaces, from cars and caravans to windows and garden furniture.	□
High Pressure Replacement Hose with Anti-Twist system and Quick Connect system									
H 10 Q PremiumFlex Anti-Twist	30	2.643-585.0						The new Kärcher anti-twist high-pressure hose makes working with your pressure washer that much easier. Thanks to the anti-twist system knots in the high-pressure hose untie themselves.	□
High-pressure hose extension - System from 2009									
High-pressure replacement hose, 9 m, K3 - K7	31	2.641-721.0						9 m high-pressure replacement hose for K3 – K7 series domestic pressure washers from 2009, where the hose is connected to the gun and pressure washer per Quick Connect connector, 160 bar, 60 °C.	□
High-pressure hose replacement kit - from 1992									
Adapter Set Extension Hose	32	2.643-037.0							□

■ Included in delivery. □ Available accessories.

K 2 FULL CONTROL
1.673-402.0

KÄRCHER

33

34

35


36

37

38

		Order Number					Price	Description	
High-pressure hose extension - System from 2008									
High-pressure extension hose, 6 m, K3 - K7 (for gun model "Best").	33	2.641-709.0						High-pressure extension hose for greater flexibility. 6 m robust DN 8 quality hose for durability. For K3 – K7 series from 2008 with Quick Connect connector.	☐
Miscellaneous									
G 160 Q	34	2.642-889.0							☐
Water filter	35	4.730-059.0						Water filter protects pressure washer pumps against dirt particles from dirty water.	☐
Replacement O-ring set	36	2.640-729.0							☐
Accessory kits									
Bike Cleaning accessory kit	37	2.643-551.0						The bike cleaning accessory kit from Kärcher is the perfect addition to your pressure washer to help you clean your motor bike. This kit helo you achieve the perfect clean for your bike.	☐
Wood Cleaning Accessory Kit	38	2.643-553.0						Kärcher's wood cleaning accessory kit is perfect for cleaning all wooden surfaces. From garden furniture to decking, this accessory kit will help you achieve the perfect clean.	☐

■ Included in delivery. ☐ Available accessories.

K 2 FULL CONTROL
1.673-402.0

KÄRCHER

1

2

3

4

5

6

7–8

9–10

		Order Number					Price	Description	
Connectors/Tap adaptors									
Universal hose coupling Plus	1	2.645-193.0						Universal hose coupling plus with soft plastic recessed grips for comfortable handling. Compatible with all click systems.	☐
Universal hose coupling Plus with Aqua Stop	2	2.645-194.0						Universal hose coupling plus with Aqua Stop and soft plastic recessed grips for comfortable handling. Compatible with all click systems.	☐
Universal hose coupling with Aqua Stop	3	2.645-192.0						Universal hose coupling with Aqua Stop. Ergonomic design for convenient handling.	☐
Universal hose coupling	4	2.645-191.0						Our universal hose coupling is an essential part of the Kärcher garden irrigation system, extending the length of your hose to make sure every inch of your garden gets the care it deserves.	☐
Hoses									
Connection Set for high-pressure cleaners	5	2.645-156.0						Hose set for high pressure cleaning or for watering the garden. With 10 m PrimoFlex®-hose (3/4"), G3/4-tap adapter, 1 x Universal hose connector as well as Universal hose connector with Aqua Stop.	☐
Indoor Hose Connection Set	6	2.645-258.0						This indoor hose connection set provides the perfect solution if you need to connect your power washer to an indoor tap.	☐
PrimoFlex® Hose: 1/2" - 20m	7	2.645-138.0						This PrimoFlex® hose is durable, with a woven reinforced garden hose with pressure resistant features and operating temperature range from -20 to 65°C, making it ideal for gardening.	☐
PrimoFlex® hose 3/4" - 25 m	8	2.645-142.0						PrimoFlex® quality garden hose (3/4") 25 m. Pressure-resistant, reinforced braided. Unharmful to health. Bursting pressure: 24 bar. Wide operating temperature range from -20 to 65 °C.	☐
Hose Storage and Hose Trolley									
Premium Hose Reel HR 7.315 Kit 5/8"	9	2.645-165.0						Watering Station for the practical and space-saving storage of hoses and garden accessories. With removable drum, storage for nozzles, spray guns, and spray lances and spacious storage box.	☐
Premium Hose Reel HR 7.315 Kit 1/2"	10	2.645-164.0						Watering Station for the practical and space-saving stowage of hoses and garden accessories. With removable drum, storage for nozzles, spray guns, and spray lances and spacious storage box.	☐

■ Included in delivery. ☐ Available accessories.